

Mini Hi-Fi Component System

Operating Instructions



MHC-W550

WARNING

To prevent fire or shock hazard, do not expose the unit to rain or moisture.


To avoid electrical shock, do not open the cabinet. Refer servicing to qualified personnel only.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet.

CAUTION

Do not, under any circumstances, place the CD player/Stereo cassette deck on top of the A/V control amplifier.

Laser component in this product is capable of emitting radiation exceeding the limit for Class 1.



This appliance is classified as a CLASS 1 LASER product. The CLASS 1 LASER PRODUCT MARKING is located on the rear exterior.

The following caution label is located inside the unit.

CAUTION	: INVISIBLE LASER RADIATION, WHEN OPEN, AVOIDS EXPOSURE TO BEAM.
ADVARSEL	: USYNLIG LASERSTRÅLING VED ÅBNING NÅR SIKKERHEDSÅBRYDERE ER UDJE AF FUNKTION. UNDDÅ UDSEJTELSSE FOR STRÅLING.
VARO!	: AVATTAAESSA JA SUOJALUKITUS OHITETTAESSA OLET ALTILAINA LASERISÄTELYLLE.
VARNING	: LASERSTRÅLING NÅR DEKSEL ÅPNES OCH SPÄRREN ÄR URKOPPLAD.
ADVERSEL	: USYNLIG LASERSTRÅLING NÅR DEKSEL ÅPNES URINNE. ENTPERNING FOR STRÅLING.

This stereo system is equipped with the Dolby* B-type noise reduction system.

* Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.

“DOLBY” and the double-D symbol  are trademarks of the Dolby Laboratories Licensing Corporation.

The MHC-W550 consist of the following components:

- A/V control amplifier STR-W550
- CD player/Stereo cassette deck HCD-W550
- Speaker system SS-W550G.

Table of Contents

Getting Started

Step 1: Hooking up the system	4
Step 2: Setting the time	6
Step 3: Presetting radio stations	6
Connecting optional AV components .	7

Basic Operations

Playing a CD	10
Recording a CD	12
Listening to the radio	13
Recording from the radio	14
Playing a tape	15
Recording from a tape	17

The CD Player

Using the CD display	18
Playing the CD tracks repeatedly	18
Playing the CD tracks in random order	19
Programming the CD tracks	20
Playing CDs without interruption	21

The Tape Deck

Recording on a tape manually	22
Recording a CD by specifying track order	23

DJ Effects

Looping part of a CD	25
Flashing part of a CD	25
Waving the equalizer	26

Sound Adjustment

Adjusting the sound	27
Selecting the audio emphasis	27
Adjusting the audio emphasis	29
Making a personal audio emphasis file	30

Other Features

Singing along: Karaoke	31
Falling asleep to music	32
Waking up to music	33
Timer-recording radio programs	34

Additional Information


Precautions	36
Troubleshooting	37
Specifications	40
Index	42

Step 1: Hooking up the system

Do the following procedure 1 to 6 to hook up your system using the supplied cords and accessories.


If you set up the stereo system vertically

Be sure to place the A/V control amplifier on top of the CD player/Stereo cassette deck.




- 1** Connect the flat cord to the SYSTEM CONTROL connectors with the same color until it clicks.

To disconnect




- 2** Connect the speakers. Connect the speaker cords to the SPEAKER jacks of the same color. Keep the speaker cords away from the antennas to prevent noise.


Insert only the stripped portion.



-
- 3** Set **VOLTAGE SELECTOR** to the position of your local power line voltage.




-
- 4** Connect the FM/AM antennas. Set up the AM loop antenna, then connect it.



-
- 5** Connect the power cord to a wall outlet. Demo mode appears in the display.

-
- 6** Deactivate the demo mode by pressing **DISPLAY/DEMO** when the system is turned off. The demo mode is also deactivated when you set the time.
-

Inserting two size AA (R6) batteries into the remote



Tip

With normal use, the batteries should last for about six months. When the remote no longer operates the system, replace both batteries with new ones.

Note

If you do not use the remote for a long period of time, remove the batteries to avoid possible damage from battery leakage.


When carrying this system

Do the following to protect the CD mechanism.

- 1 Press **FUNCTION** repeatedly until "CD" appears in the display.
- 2 Hold down **PLAY MODE** and press **POWER** so that "LOCK" appears in the display.


To attach the front speaker pads

Attach the supplied front speaker pads to the bottom of the speakers to stabilize the speakers and prevent them from slipping.



Step 2: Setting the time

You must set the time before using the timer functions.



- 1 Press **CLOCK TIMER SET**.
The hour indication flashes.



- 2 Turn the jog dial to set the hour.
The clock is on a 24-hour system.

- 3 Press **ENTER/NEXT**.
The minutes indication flashes.



- 4 Turn the jog dial to set the minutes.

- 5 Press **ENTER/NEXT**.
The clock starts working.

Tips


- If you've made a mistake, start over from step 1.
- Setting the time deactivates the demo mode.
If you want to display the demo mode, press **DISPLAY/DEMO** when the system is off.

Note

When setting the time, set the equalizer display to anything other than Spectrum analyzer pattern 3. (See "To change the equalizer display" on page 28.)

Step 3: Presetting radio stations


You can preset up to 40 stations, 20 for FM, 10 for MW and 10 for SW.



- 1 Press **TUNER BAND** repeatedly until the band you want appears in the display.

Every time you press this button, the band changes as follows:


FM → MW → SW



- 2 Press **TUNING MODE** repeatedly to select "AUTO".

- 3 Turn the jog dial.


The frequency indication changes and scanning stops when the system tunes in a station. "TUNED" and "STEREO" (for a stereo program) appear.



- 4 Press **MEMORY**.

A preset number appears in the display.

Preset number



5 Turn the jog dial to select the preset number you want.

6 Press ENTER/NEXT.
The station is stored.

7 Repeat steps 1 to 6 to store other stations.

To tune in a station with a weak signal

Press TUNING MODE repeatedly to select "MANUAL" in step 2, then turn the jog dial to tune in the station.

To change the preset number

Start over from step 1.

Tip

The preset stations are retained for a day even if you unplug the power cord or if a power failure occurs.

Connecting optional AV components

To enhance your system, you can connect optional components. Refer to the instructions of each component.


Connecting audio components

Select one of the following two connections, depending on the equipment to be connected and method of connecting.

Connecting an MD deck for digital recording

You can record from CD into the MD deck digitally by connecting an optical cable.

To the DIGITAL IN jack of the MD deck




Connecting optional AV components (continued)

Connecting an MD deck for analog recording

Make sure to match the colour of the plugs and the connectors. To listen to the sound of the connected MD deck, press FUNCTION repeatedly until "MD" appears.

To the audio output of the MD deck To the audio input of the MD deck




Note

If you cannot select "MD" even when you have pressed FUNCTION, press POWER while pressing FUNCTION when the power is turned off. "VIDEO 1" will be switched to "MD". To return to "VIDEO 1" do the same procedure.

Connecting a super woofer speaker

You can connect an optional super woofer speaker.


To super woofer



Connecting a VCR

Make sure to match the colour of the plugs and the connectors. To listen to the sound of the connected VCR, press FUNCTION repeatedly until "VIDEO 1" appears.

To the audio output of the VCR





Note

If the sound is distorted when selecting "VIDEO 1", switch to "MD" (see previous "Note").

Connecting a video game player

You can enjoy video games with audio emphasis by connecting a video game player. To listen to and watch a video game, press FUNCTION repeatedly until "VIDEO 2" appears.

To the audio/video output of a video game player




To the video input of a TV

Connecting outdoor antennas

Connect the outdoor antenna to improve the reception.


FM antenna

Connect the optional FM outdoor antenna. You can also use the TV antenna instead.



AM antenna

Connect a 6- to 15- meter insulated wire to the AM antenna terminal. Leave the supplied AM loop antenna connected.






Important

If you connect an outdoor antenna, connect a ground wire to the h terminal with the screw clamp. To prevent a gas explosion, do not connect the ground wire to a gas pipe.

Playing a CD

— Normal play

You can play up to three CDs in a row.




- 1 Press **▲ OPEN/CLOSE** and place up to two CDs on the disc tray. If a disc is not placed properly it will not be recognized.

With the label side up. When you play a single CD, place it on the inner circle of the tray.



To insert a third disc, press **DISC SKIP EX-CHANGE** to rotate the disc tray.

- 2 Press one of the **DISC 1~3** buttons. The disc tray closes and playback starts. If you press **▶||** (or **▶||** on the remote), playback starts from the CD loaded on the tray whose button is lit green.



To	Do this
Stop playback	Press ■ (■ on the remote).
Pause	Press ▷ (on the remote). Press again to resume playback.
Select a track	During playback or pause, turn the jog dial clockwise (to go forward) or counterclockwise (to go back) and release it when you reach the desired track. Or press ▶▶ (to go forward) or ◀◀ (to go back) on the remote.
Find a point in a track	Press and hold down ▶▶ or ◀◀ (or ▶▶/◀◀ on the remote) during playback and release it at the desired point.
Select a CD in stop mode	Press one of the DISC 1-3 buttons or DISC SKIP EX-CHANGE.
Play only the CD you have selected	Press 1/ALL DISCS repeatedly until "1 DISC" appears.
Play all CDs	Press 1/ALL DISCS repeatedly until "ALL DISCS" appears.
Remove the CD	Press ▲ OPEN/CLOSE.
Exchange other CDs while playing	Press DISC SKIP EX-CHANGE.
Adjust the volume	Turn VOLUME (or press VOL +/- on the remote).


Tips

- Pressing **▷||** when the power is off automatically turns the power on and starts CD playback if there is a CD in the tray (One Touch Play).
- You can switch from another source to the CD player and start playing a CD just by pressing **▷||** or one of the DISC 1-3 buttons (Automatic Source Selection).
- If there is no CD in the player, "CD NO DISC" appears in the display.
- When a disc tray is selected or the CD placed on that tray is playing, the DISC 1-3 button for the respective tray lights green.

Recording a CD


— CD Synchro Recording

The CD SYNCHRO button lets you record from a CD to a tape easily. You can use TYPE I (normal) or TYPE II (CrO₂) tapes. The recording level is adjusted automatically.



- 1 Press and insert a blank tape into deck B.

With the side you want to record facing forward




- 2 Press OPEN/CLOSE and place a CD.

Then press again to close the disc tray.

If the indicator for the tray you want to record is not lit green, press DISC SKIP EX-CHANGE repeatedly so that it lights green.

With the label side up. When you play a single CD, place it on the inner circle of the tray.



- 3 Press CD SYNCHRO.
Deck B stands by for recording and the CD player stands by for playback. (for front side) lights up.
- 4 Press DIRECTION MODE repeatedly to select to record on one side. Select (or RELAY) to record on both sides.
- 5 Press PAUSE on deck B.
Recording starts.

To stop recording

Press on deck B or on the CD player.

Tips

- If you want to record from the reverse side, press so that (for reverse side) lights up.
- When you record on both sides, be sure to start from the front side. If you start from the reverse side, recording stops at the end of the reverse side.
- When you want to reduce the hiss noise in low-level high-frequency signals, press DOLBY NR so that "DOLBY NR B" appears after pressing CD SYNCHRO.



Notes

- You cannot listen to other sources while recording.
- Dolby NR and DIRECTION MODE (or RELAY) is off when the mains AC power supply is switched off.

Listening to the radio

-- Preset Tuning

Preset radio stations in the tuner's memory first (see "Step 3: Presetting radio stations").



1 Press TUNER BAND repeatedly until the band you want appears in the display.

Every time you press the button, the band changes as follows:

FM → MW → SW




2 Press TUNING MODE repeatedly so that "PRESET" appears in the display.

MANUAL → AUTO → PRESET




3 Turn the jog dial (or press ◀◀ or ▶▶ on the remote) to tune in the desired preset station.

Turn counter-clockwise (or press ◀◀ on the remote) for lower preset numbers.



Turn clockwise (or press ▶▶ on the remote) for higher preset numbers.



To	Do this
Turn off the radio	Press POWER.
Adjust the volume	Turn VOLUME (or press VOL +/- on the remote).

To listen to non-preset radio stations


Press TUNING MODE repeatedly so that "MANUAL" appears in step 2, then tune in the station by turning the jog dial.

Tips

- Pressing TUNER BAND when the power is off automatically turns the power on and tunes to the last received station (One Touch Play).
- You can switch from another source to the radio just by pressing TUNER BAND (Automatic Source Selection).
- When an FM program is noisy, press STEREO/MONO so that "MONO" appears in the display. There will be no stereo effect, but the reception will improve. Press the button again to restore the stereo effect.
- To improve broadcast reception, reorient the supplied antennas.

Recording from the radio

You can record the radio program on a tape by calling up a preset station. You can use TYPE I (normal) or TYPE II (CrO₂) tapes. The recording level is automatically adjusted.




1 Press TUNER BAND to select the band you want.


2 Press TUNING MODE so that "PRESET" appears in the display.

3 Turn the jog dial to tune in a preset station.

Turn counter-clockwise for lower preset numbers.




Turn clockwise for higher preset numbers.



4 Press and insert a blank tape into deck B.

With the side you want to record facing forward



5 Press REC.
Deck B stands by for recording.

6 Press DIRECTION MODE repeatedly to select to record on one side. Select (or RELAY) to record on both sides.

7 Press PAUSE on deck B.
Recording starts.

To stop recording

Press on deck B.

Tips


- If you want to record from the reverse side, press so that (for reverse side) lights up.
- When you record on both sides, be sure to start from the front side. If you start from the reverse side, recording stops at the end of the reverse side.
- To record non-preset stations, select "MANUAL" in step 2, then turn the jog dial to tune in the desired station.
- When you want to reduce the hiss noise in low-level high-frequency signals, press DOLBY NR so that "DOLBY NR B" appears after pressing REC.
- If noise is heard while recording from the radio, move the respective antenna to reduce the noise.

Note

Dolby NR and DIRECTION MODE (or RELAY) is off when the mains AC power supply is switched off.


Playing a tape

You can use any type of tape, TYPE I (normal), TYPE II (CrO₂) or TYPE IV (metal), since the deck automatically detects the tape type. To select either deck A or B, press DECK A or DECK B on the remote.



- 1 Press and insert a recorded tape in deck A or B.

With the side you want to play facing forward



- 2 Press DIRECTION MODE repeatedly to select to play one side. Select to play both sides. To play both decks in succession, select RELAY (relay play).**

- 3 Press . Press to play the reverse side. The tape starts playing.

* The deck stops automatically after repeating the sequence five times.

** Relay play always follows the following sequence:

Deck A (front side), Deck A (reverse side), Deck B (front side), Deck B (reverse side).

To	Do this
Stop playback	Press (or on the remote).
Pause (Deck B only)	Press PAUSE . Press again to resume play.
Fast-forward	Press while playing the front side or while playing the reverse side.
Rewind	Press while playing the front side or while playing the reverse side.
Remove the cassette	Press .
Adjust the volume	Turn VOLUME (or press VOL +/- on the remote).

Playing a tape (continued)

Tips

- Pressing ▷ or ◁ when the power is off automatically turns the power on and starts tape playback if there is a tape in the deck (One Touch Play).
- You can switch from another source to the tape deck just by pressing ▷ or ◁ (Automatic Source Selection).
- If the tape you want to play is recorded with DOLBY NR B, you can reduce the noise by pressing the DOLBY NR so that "DOLBY NR B" appears.
- When dubbing tapes originally recorded with Dolby NR B, the dubbed tape is automatically played with Dolby NR B.


Note

Dolby NR and DIRECTION MODE (↔ or RELAY) is off when the mains AC power supply is switched off.

Recording from a tape


— High-speed Dubbing

You can use TYPE I (normal) or TYPE II (CrO₂) tapes. The recording level is automatically adjusted.



- 1 Press and insert a recorded tape in deck A and a blank tape in deck B.

With the side you want to play/record facing forward



- 2 Press HI-SPEED DUBBING.
Deck B stands by for recording.
- 3 Press DIRECTION MODE repeatedly to select to record on one side. Select (or RELAY) to record on both sides.

- 4 Press PAUSE .
Dubbing starts.

To stop dubbing

Press on deck A or B.

Tips


- When you dub on both sides, start recording from the front side. If you record from the reverse side, recording stops at the end of the reverse side.
- If you set DIRECTION MODE to when the tapes you use have different lengths, the tape in each deck reverses independently. If you select RELAY, the tapes in both decks reverse together.
- You don't have to set DOLBY NR, since the tape in deck B is automatically recorded in the same state as the tape in deck A.

Note

Dolby NR and DIRECTION MODE (or RELAY) is off when the mains AC power supply is switched off.


Using the CD display

You can check the remaining time of the current track or that of the CD.



➔ Press DISPLAY/DEMO during playback.

Each time you press the button during normal playback, the display changes as follows:



To check the total playing time and the number of tracks on a CD


Press DISPLAY/DEMO in the stop mode.

If you press DISPLAY/DEMO again, the clock display appears for eight seconds then the display returns to the previous indication.

Playing the CD tracks repeatedly

-- Repeat Play

This function lets you repeat a single CD or all CDs in normal play, Shuffle Play and Program Play.



➔ Press REPEAT during playback until "REPEAT" appears in the display.

Repeat Play starts. Do the following procedure to change the repeat mode.

To repeat	Press
All the tracks on the current CD	1/ALL DISCS repeatedly until "1 DISC" appears in the display.
All the tracks on all CDs	1/ALL DISCS repeatedly until "ALL DISCS" appears in the display.
Only one track*	REPEAT repeatedly until "REPEAT 1" appears in the display while playing the track you want to repeat.

* You can't repeat a single track during Shuffle Play and Program Play.


To cancel Repeat Play

Press REPEAT so that "REPEAT" or "REPEAT 1" disappears from the display.

Playing the CD tracks in random order

— Shuffle Play

You can play all the tracks on one CD or all CDs in random order.



To cancel Shuffle Play

Press PLAY MODE repeatedly until "SHUFFLE" or "PROGRAM" disappears from the display. The tracks continue playing in their original order.

To select a desired CD

Press DISC 1~3.

Tips

- You can start Shuffle Play during normal playback by pressing PLAY MODE repeatedly to select "SHUFFLE".
- To skip a track, turn the jog dial clockwise (or press ►► on the remote).

1 Press FUNCTION repeatedly until "CD" appears in the display, then place a CD.

2 Press PLAY MODE repeatedly until "SHUFFLE" appears in the display.


3 Press 1/ALL DISCS to choose "1 DISC" or "ALL DISCS".
"ALL DISCS" shuffles all the CDs in the player. "1 DISC" shuffles the CD whose DISC indicator is green.

4 Press ►►.
"◻" appears and then all the tracks play in random order.


Programming the CD tracks

— Program Play


You can make a program of up to 32 tracks from all the CDs in the order you want them to be played.



- 1** Press FUNCTION repeatedly until “CD” appears in the display, then place a CD.
- 2** Press PLAY MODE repeatedly until “PROGRAM” appears in the display.
- 3** Press one of the DISC 1~3 buttons to select a CD.
- 4** Turn the jog dial until the desired track appears in the display.



- 5** Press ENTER/NEXT. The track is programmed. “STEP” and the programmed playing order appear, followed by the total playing time.



- 6** To program additional tracks, repeat steps 3 to 5. Skip step 3 to select tracks from the same disc.
- 7** Press ▷||. All the tracks play in the order you selected.

To cancel Program Play

Press PLAY MODE repeatedly until “PROGRAM” or “SHUFFLE” disappears from the display.

To	Press
Check the program	CHECK on the remote repeatedly. After the last track, "CHECK END" appears.
Clear a track from the end	CLEAR on the remote in stop mode.
Clear a specific track	CHECK on the remote repeatedly until the number of the track to be erased lights up, then press CLEAR.
Add a track to the program	1 Select the disc tray with one of the DISC 1-3 buttons. 2 Select the track by turning the jog dial. 3 Press ENTER/NEXT.
Clear the entire program	■ once in stop mode or twice while playing.


Tips

- The program you made remains in the CD player even after it has been played back. Press ▷|| to play the same program again.
- If "--:--" appears instead of the total playing time during programming, this means:
 - you have programmed a track number which exceeds 20
 - the total playing time has exceeded 100 minutes.

Playing CDs without interruption

-- Non-Stop Play

You can play CDs without pausing between tracks.



1 Press FUNCTION repeatedly until "CD" appears in the display, then place a CD.

2 Press and hold down ▷|| until "NON STOP PLAY" appears and the disc number blinks.

To cancel Non-Stop Play


Press and hold down ▷|| until "NON STOP PLAY OFF" appears.
The disc number stops blinking.

Note

"NON STOP PLAY" also works for CD synchro recording.

Recording on a tape manually

You can record from CD, tape, or radio as you like. For example, you can record just the songs you want or record from the middle of the tape. The recording level is adjusted automatically.



- 1** Insert a blank tape into deck B.
- 2** Press FUNCTION repeatedly until the source you want to record (e.g. CD) appears.
- 3** Press REC.
Deck B stands by for recording. ▷ (for front side) lights up.
- 4** Press DIRECTION MODE repeatedly to select ↔ to record on one side. Select ↻ (or RELAY) to record on both sides.

- 5** Press PAUSE || on deck B.
Recording starts.

- 6** Start playing the source to be recorded.

To	Press
Stop recording	□ on the deck B
Pause recording	PAUSE on the deck B

Tips

- If you want to record from the reverse side, press ◀ so that ◀ (for reverse side) lights up.
- When you want to reduce the hiss noise in low-level high-frequency signals, press DOLBY NR so that "DOLBY NR B" appears after pressing REC.



Note

Dolby NR and DIRECTION MODE (↔ or RELAY) is off when the mains AC power supply is switched off.


Recording a CD by specifying track order

— Program Edit


You can record tracks from all the CDs in the order you want. When programming, make sure the playing times for each side do not exceed the length of one side of the tape.



- 1 Place a CD and insert a blank tape into deck B.
- 2 Press FUNCTION repeatedly until "CD" appears in the display.
- 3 Press PLAY MODE repeatedly until "PROGRAM" and "DISC" appear in the display.
- 4 Press one of the DISC 1~3 buttons to select a CD.
- 5 Turn the jog dial until the desired track appears in the display.



- 6 Press ENTER/NEXT. The track is programmed. "STEP" and the programmed playing order appear, followed by the total playing time.



- 7 To program additional tracks to be recorded on side A, repeat steps 4 to 6. Skip step 4 to select tracks from the same disc.

Recording a CD by specifying track order (continued)

-
- 8** Press **II** on the remote to insert a pause at the end of side A. “P” appears in the display and the total playing time resets to “0.00” in the display.
-
- 9** Repeat steps 5 and 6 for tracks from the same disc or steps 4 to 6 for tracks from another disc to program the remaining tracks to be recorded on side B.
-

- 10** Press CD SYNCHRO.
Deck B stands by for recording and the CD player stands by for playback. \triangleright (for front side) lights up.
-

- 11** Press DIRECTION MODE repeatedly to select \rightleftarrows to record on one side. Select \leftrightarrow (or RELAY) to record on both sides.
-

- 12** Press PAUSE **II** on deck B.
Recording starts.
-

To stop recording

Press \square on the deck B or \blacksquare on the CD player.

To check the order

Press CHECK on the remote repeatedly. After the last track, “CHECK END” appears.

To cancel Program Edit

Press PLAY MODE repeatedly until “PROGRAM” or “SHUFFLE” disappears from the display.

Selecting tape length automatically

— Tape Select Edit

You can check the most suitable tape length for recording a CD. Note that you cannot use Tape Select Edit for discs containing more than 20 tracks.

- ➔** After inserting a CD, press EDIT once, so that “EDIT” flashes.
The required tape length for the currently selected CD appears, followed by the total playing time and tracks for side A and side B.
-


Notes

- You cannot use this function after programming. In order to use this function, you must first erase the program (see “To clear the entire program” on page 21).
- Dolby NR and DIRECTION MODE (\leftrightarrow or RELAY) is off when the mains AC power supply is switched off.

Looping part of a CD

— Loop

With the loop function, you can repeat part of a CD during playback. This lets you create original recordings.



➔ Press and hold LOOP during playback at the point you want to start the Loop function, and release to resume normal play.


To adjust the loop length

Turn the jog dial while holding LOOP (or press MUSIC MENU ◀ or ▶ while holding LOOP on the remote) to select different loop lengths (LOOP 1~20).

Flashing part of a CD

— Flash

With the flash function, you can “flash” the CD sound during playback. This lets you create original recordings.



➔ Press and hold FLASH during playback at the point you want to start the Flash function, and release to resume normal playback.

To adjust the flash length

Turn the jog dial while holding FLASH (or press MUSIC MENU ◀ or ▶ while holding FLASH on the remote) to select different flash lengths (FLASH 1~20).

To use LOOP and FLASH together

Press and hold both LOOP and FLASH at the same time.


Notes

- The loop and flash length cannot be adjusted during this operation. Adjust the loop and flash lengths independently beforehand if necessary.
- To record the flash effect, use the analog MD/VIDEO 1 OUT connections or this unit's tape deck.

Waving the equalizer

— Wave

With the Wave function, you can fluctuate the graphic equalizer automatically. This effect can be used with any source, but it cannot be recorded.




➔ Press and hold WAVE to start the Wave function, and release to resume normal listening.

To adjust the wave length

Turn the jog dial while holding WAVE to select a different wave length (WAVE 1~10).

Adjusting the sound

You can reinforce the bass, create a more powerful sound, and listen with headphones.



To reinforce bass (DBFB)

Press DBFB*.

Every time you press the button, the display changes as follows:

DBFB ■■■ → DBFB ■■■■■ → DBFB OFF

“DBFB ■■■■■” is more effective than “DBFB ■■■”.

If DBFB effect is on, “DBFB” button lights up.

* DBFB = Dynamic Bass Feedback

For a powerful sound (GROOVE)

Press GROOVE. The volume switches to power mode, DBFB is automatically set to full strength, the equalizer curve changes, and the “GROOVE” button lights up. Press GROOVE again to return to the previous volume.

Notes

- With some songs, the music will sound distorted when you use the DBFB system with the graphic equalizer if the bass is too strong. Adjust the bass slowly while listening to music so that you can monitor the effect of the adjustment.
- Cancelling GROOVE sets DBFB to “OFF” and flattens the equalizer curve. To obtain the DBFB effect, press DBFB until “DBFB” button lights up. Adjust the equalization to obtain the effect you desire.


To listen through the headphones

Connect the headphones to PHONES jack. No sound will come from the speakers.

Selecting the audio emphasis

The audio emphasis menu lets you select the sound characteristic according to the sound you are listening to.

The personal file function (see “Making a personal audio emphasis file” on page 30) lets you store your own effects.



1 Press MUSIC, MOVIE, or GAME (or MUSIC MENU \uparrow/\downarrow on the remote repeatedly) to select a menu.

See the chart “Music menu options” in the next page. The last effect chosen from that menu appears in the display.

2 Use the jog dial (or press MUSIC MENU \leftarrow/\rightarrow on the remote repeatedly) to select the preset you desire.

The preset name appears in the display.

3 Press ENTER/NEXT.
You don’t need to press ENTER/NEXT when you use the remote.


Adjusting the audio emphasis

You can adjust the audio emphasis using the graphic equalizer and surround effect.

Adjusting the graphic equalizer


You can adjust the sound by raising or lowering the levels of specific frequency ranges.

Before operation, first select the audio emphasis you want for your basic sound.




1 Select the audio emphasis you want for your basic sound (see “Selecting the audio emphasis” on page 27).

2 Press HIGH FREQ or LOW FREQ repeatedly to select a frequency band.



3 Turn the jog dial to adjust level.



4 Repeat steps 2 and 3.


5 Press ENTER/NEXT when finished.

Note

If you choose another menu of audio emphasis (other than “EFFECT OFF”), the adjusted sound effect is lost. To retain the adjusted sound effect for future use, store it in a personal file. (See “Making a personal audio emphasis file” on page 30.)

Activating the surround effect

You can enjoy the surround effect.



➔ Press SURROUND repeatedly so that “SUR |||||” appears in the display.

Note


When you choose other sound effects, the surround effects will be canceled. If you want to memorize the effect, store it into a personal file (see “Making a personal audio emphasis file” on page 30).

Making a personal audio emphasis file

— Personal file

You can create a personal file of audio patterns (surround effect and graphic equalizer) and store them in the memory of the unit. Later call up an audio pattern to play a favorite tape, CD, or radio program. You can create up to five audio files.

Before operation, first select the audio emphasis you want for your basic sound.



-
- 1 Obtain the sound effect you want by using the graphic equalizer and surround effect. (See “Adjusting the Audio Emphasis”)

-
- 2 Press **MEMO** .
The personal file number appears in the display.



-
- 3 Use the jog dial to select the file number (P FILE) where you want to store the sound effect.

-
- 4 Press ENTER/NEXT.
The adjusted sound effects are stored under the selected file number. The settings previously stored at this memory location are erased and replaced by the new settings.
-

To call up the personal file


- 1 Press P FILE (or MUSIC MENU \uparrow/\downarrow on the remote repeatedly) to display the last selected personal file.
- 2 Use the jog dial (or press MUSIC MENU \leftarrow/\rightarrow on the remote repeatedly) to select the personal file you desire.
- 3 Press ENTER/NEXT.
You don't need to press ENTER/NEXT when you use the remote.

Tip

The programmed P file will be retained for a day if the power cord is unplugged or there is a power failure.

Singing along: Karaoke

You can sing along with any stereo CD or tape by turning down the singer's voice. You need to connect an optional microphone.



1 Turn MIC LEVEL to MIN to turn down the microphone control level.

2 Connect an optional microphone to MIX MIC.

3 Press KARAOKE PON/MPX repeatedly to obtain the karaoke effect you desire.

Every time you press the button, the display changes as follows:

KARAOKE PON → MPX R → MPX L

↑ Effect (or P FILE) name or "EFFECT ON (OFF)" ↓

The indicator appears in the display when a karaoke mode is activated.

To sing karaoke with decreasing the vocal level of a CD, select KARAOKE PON. To sing karaoke of multiplex CD or tape, select MPX R or MPX L.


4 Start playing the music and adjust the volume.

5 Adjust the microphone volume by turning MIC LEVEL.

When you are done

Turn MIC LEVEL to MIN and disconnect the microphone from MIX MIC, then press KARAOKE PON/MPX repeatedly so that disappears.

Mixing and recording sounds



1 Do the above steps 1 to 5. Then, insert a tape in deck B.

2 Press FUNCTION repeatedly to select the source you desire and set it to pause mode.

Singing along: Karaoke (continued)

3 Press REC.

4 Press PAUSE ■.

5 Start playing the source selected in Step 2.

Playback starts. Start singing along with the music.

To stop recording

Press □ on deck B and ■ on the CD player.

Tips

- If acoustic feedback (howling) occurs, move the microphone away from the speakers or change the direction of the microphone.
- If you want to record your voice through the microphone only, you can do so by selecting the CD function and not playing a CD.


Notes

- If you press EFFECT ON/OFF or recall a sound effect, the karaoke mode is cancelled.
- The instrumental sound may be reduced as well as the singer's voice when the sound is recorded in monaural.
- The singer's voice may not be reduced when:
 - only a few instruments are playing
 - a duet is being played
 - the source has strong echoes or chorus
 - the singer's voice deviates from the centre
 - the voice on the source is singing in high soprano or tenor.

Falling asleep to music

— Sleep Timer

You can let the system turn off at the preset time, so you can sleep to the music. You can preset the time to be turned off by 10 minutes.



➔ Press SLEEP on the remote.

Every time you press the button, the minutes display (the turn-off time) changes as follows:

AUTO → 90min → 80min → 70min
→ ... → 10min → OFF → AUTO ...

When you choose auto

The power turns off when the current CD or tape finishes playback (for up to 100 minutes).

To check the remaining time

Press SLEEP on the remote once.

To change the time to turn off

Select the time you want by pressing SLEEP on the remote.


To cancel the Sleep Timer function

Press SLEEP on the remote repeatedly until "OFF" appears.

Waking up to music

— Wake-up Timer

You can wake up to music at a preset time every day. Make sure you have set the clock (see “Step 2: Setting the time”).




- 1 Prepare the music source you want to play.
 - CD: Insert a CD. To start from a specific track, make a program (see “Programming the CD tracks”).
 - Tape: Insert a tape with the side you want to play facing forward.
 - Radio: Tune in the preset station you want (see “Step 3: Presetting radio stations”).


- 2 Adjust the volume.

- 3 Press CLOCK TIMER SET.
“SET (DAILY 1)” appears.

- 4 Turn the jog dial to select DAILY 1 or 2, then press ENTER/NEXT.
“ON” appears and the hour digits flash in the display.



- 5 Set the time to start playback.
Turn the jog dial to set the hour, then press ENTER/NEXT.
The minutes indication starts flashing.



Turn the jog dial to set the minutes, then press ENTER/NEXT.
The hour indication flashes again.

- 6 Set the time to stop playback following the above procedure.

- 7 Turn the jog dial until the music source you want appears.
The indications change as follows:
TUNER → CD PLAY → TAPE PLAY

- 8 Press ENTER/NEXT.
The start time appears, followed by the stop time and the music source, then the original display appears.

- 9 Turn off the power.

Waking up to music (continued)

To check the setting

Press **TIMER SELECT** and turn the jog dial to select the respective mode (**DAILY 1** or **DAILY 2**), then press **ENTER/NEXT**. To change the setting, start over from step 1.

To cancel the timer operation

Press **TIMER SELECT** and turn the jog dial to select **"OFF"**, then press **ENTER/NEXT**.

Tip


The power turns on 15 seconds before the preset time.

Note

When setting the wake-up timer, set the equalizer display to anything other than Spectrum analyzer pattern 3. (See "To change the equalizer display" on page 28.)

Timer-recording radio programs


To timer-record, you must preset the radio station (see "Step 3: Presetting radio stations") and set the clock (see "Step 2: Setting the time") beforehand.



-
- 1** Tune in the preset radio station (see "Listening to the radio").
 - 2** Press **CLOCK TIMER SET**.
"SET (DAILY 1)" appears.
-

-
- 3** Turn the jog dial to select REC, then press ENTER/NEXT.


“ON” appears and the hour digits flash in the display.



-
- 4** Set the time to start recording.

Turn the jog dial to set the hour, then press ENTER/NEXT.

The minutes indication starts flashing.



Turn the jog dial to set the minutes, then press ENTER/NEXT.

The hour indication flashes again.

-
- 5** Set the time to stop recording following the above procedure.

The start time appears, followed by the stop time, the recording source and the radio station, then the original display appears.

-
- 6** Insert a recordable tape.

-
- 7** Turn off the power.

When the recording starts, the volume level is set to the minimum.

To check the setting

Press TIMER SELECT and turn the jog dial to select “REC”, then press ENTER/NEXT. To change the setting, start over from step 1.

To cancel the timer operation

Press TIMER SELECT and turn the jog dial to select “OFF”, then press ENTER/NEXT.

Notes

- When setting the timer-recording, set the equalizer display to anything other than Spectrum analyzer pattern 3. (See “To change the equalizer display” on page 28.)
- If the power is on at the preset time, the recording will not be made.

Precautions

On operating voltage

Before operating the system, check that the operating voltage of your system is identical with the voltage of your local power supply.

On safety

- The unit is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the unit itself has been turned off.
- Unplug the system from the wall outlet (mains) if it is not to be used for an extended period of time. To disconnect the cord (mains lead), pull it out by the plug. Never pull the cord itself.
- Should any solid object or liquid fall into the component, unplug the stereo system and have the component checked by qualified personnel before operating it any further.
- The AC power cord must be changed only at the qualified service shop.

On placement

- Place the stereo system in a location with adequate ventilation to prevent heat build-up in the stereo system.
- Do not place the unit in an inclined position.
- Do not place the unit in locations where it is;
 - Extremely hot or cold
 - Dusty or dirty
 - Very humid
 - Vibrating
 - Subject to direct sunlight

On operation

- If the stereo system is brought directly from a cold to a warm location, or is placed in a very damp room, moisture may condense on the lens inside the CD player. Should this occur, the system will not operate properly. Remove the CD and leave the system turned on for about an hour until the moisture evaporates.
- When you move the system, take out any discs.

If you have any questions or problems concerning your stereo system, please consult your nearest Sony dealer.

Notes on CDs

- Before playing, clean the CD with a cleaning cloth. Wipe the CD from the center out.
- Do not use solvents such as benzene, thinner, commercially available cleaners or anti-static spray intended for vinyl LPs.
- Do not expose the CD to direct sunlight or heat sources such as hot air ducts, nor leave it in a car parked in direct sunlight.

Cleaning the cabinet


Use a soft cloth slightly moistened with mild detergent solution.

To remove the speaker grille


Use both hands and pull straight forward to prevent the ribs from breaking.

To save a tape permanently

To prevent a tape from being accidentally recorded over, break off the cassette tab from side A or B as illustrated. If you later want to reuse the tape for recording, cover the broken tab with adhesive tape.



When you are using a TYPE II (CrO₂) or TYPE IV (metal) cassette, be careful not to cover the detector slots which allow the tape player to automatically detect the type of tape.



Before placing a cassette in the tape deck

Take up any slack in the tape. Otherwise the tape may get entangled in the parts of the tape deck and become damaged.

When using a tape longer than 90 minutes

The tape is very elastic. Do not change the tape operations such as play, stop, and fast-winding etc. frequently. The tape may get entangled in the tape deck.

Cleaning the tape heads

Clean the tape heads after every 10 hours of use.

When the tape heads become dirty

- the sound is distorted
- there is a decrease in sound level
- the sound drops out
- the tape does not erase completely
- the tape does not record

Make sure to clean the tape heads before you start an important recording or after playing an old tape. Use separately sold dry-type or wet-type cleaning cassette. For details, refer to the instructions of the cleaning cassette.

Demagnetizing the tape heads

Demagnetize the tape heads and the metal parts that have contact with the tape every 20 to 30 hours of use with a separately sold demagnetizing cassette. For details, refer to the instructions of the demagnetizing cassette.

Troubleshooting

If you run into any problem using this stereo system, use the following check list.

First, check that the power cord is connected firmly and the speakers are connected correctly and firmly.

Should any problem persist, consult your nearest Sony dealer.

General

The display starts flashing as soon as you plug in the power cord even though you haven't turned on the power (demonstration mode).

- Press DISPLAY/DEMO when the power is turned off.

The demonstration mode appears automatically the first time you plug in the power cord. If there is a power outage lasting longer than a day, do the following again:

- Clock setting (see “Step 2: Setting the time”)
- Preset stations (see “Step 3: Presetting radio stations”)
- Timer settings (see “Waking up to music” and “Timer-recording radio programs”).

“0:00” flashes in the display.

- A power interruption occurred. Set the clock and timer settings again.

There is no sound.

- Rotate VOLUME clockwise.
- The headphones are connected.
- Insert only the stripped portion of the speaker cord into the SPEAKER jack. Inserting the vinyl portion of the speaker cord will obstruct the speaker connections.

Troubleshooting (continued)

There is severe hum or noise.

- A TV or VCR is placed too close to the stereo system. Move the stereo system away from the TV or VCR.
-

The sound from the connected source is distorted.

- If “VIDEO 1” appears in the display when you press FUNCTION, switch the display to “MD” (see “Notes: Connecting a VCR” on page 8).
-

The timer does not function.

- Set the clock correctly.
-

DAILY1, DAILY 2, and REC do not appear when you press the TIMER SELECT button.

- Set the clock.
 - Set the timer correctly.
-

The remote does not function.

- There is an obstacle between the remote and the system.
 - The remote is not pointing in the direction of the system’s sensor.
 - The batteries have run down. Replace the batteries.
-

There is acoustic feedback.

- Decrease the volume level.
 - Move the microphone away from the speakers or change the direction of the microphone.
-

The color irregularity on a TV screen persists.

- Place the speakers farther away from the TV set.
-

Speakers

Sound comes from one channel or unbalanced left and right volume.

- Check the speaker connection and speaker placement.
-

CD Player

The CD tray does not close.

- The CD is not placed properly.
-

The CD will not play.

- The CD is not lying flat in the disc tray.
 - The CD is dirty.
 - The CD is inserted label side down.
 - Moisture condensation has built up. Remove the CD and leave the system turned on for about an hour until the moisture evaporates.
-

Play does not start from the first track.

- The player is in program or shuffle mode. Press PLAY MODE repeatedly until “PROGRAM” or “SHUFFLE” disappear.
-

“OVER” is displayed.

- You have reached the end of the CD. Press and hold ◀◀ to return.
-

Tape Deck

The tape does not record.

- No tape in the cassette holder.
- The tab has been removed from the cassette (see “To save a tape permanently” on page 36).
- The tape has reeled to the end.

The tape does not record nor play or there is a decrease in sound level.

- The heads are dirty. Clean them (see “Cleaning the tape heads” on page 37).
- The record/playback heads are magnetized. Demagnetize them (see “Demagnetizing the tape heads” on page 37).

The tape does not erase completely.

- The record/playback heads are magnetized. Demagnetize them (see “Demagnetizing the tape heads” on page 37).

There is excessive wow or flutter, or the sound drops out.

- The capstans or pinch rollers are dirty. Clean them (see “Cleaning the tape heads” on page 37).

Noise increases or the high frequencies are erased.

- The record/playback heads are magnetized. Demagnetize them (see “Demagnetizing the tape heads” on page 37).
-

Tuner

Severe hum or noise (“TUNED” or “STEREO” flashes in the display.)

- Adjust the antenna.
- The signal strength is too weak. Connect the external antenna.

A stereo FM program cannot be received in stereo.

- Press STEREO/MONO so that “STEREO” appears.
-

If other troubles not described above occur, reset the system as follows:

- 1 Unplug the power cord.
- 2 Plug the power cord back in.
- 3 Press DISPLAY/DEMO, ENTER/NEXT, and REPEAT at the same time.

Specifications

Amplifier section

DIN power output	80 W + 80 W (6 ohms at 1 kHz, DIN)
Music power output	190 W + 190 W (6 ohms at 1 kHz, 10% THD)
Inputs	MD/VIDEO 1 IN (phono jacks): voltage 250 mV, impedance 47 kilohms AV INPUT AUDIO (phono jacks): voltage 250 mV, impedance 47 kilohms MIX MIC (phone jack): sensitivity 1 mV, impedance 10 kilohms MD/VIDEO 1 OUT (phono jacks): voltage 250 mV, impedance 1 kilohm PHONES (stereo phone jack): accepts headphones of 8 ohms or more. SPEAKER: accepts impedance of 6 to 16 ohms SUPER WOOFER: Voltage 1 V, impedance 1 kilohm
Outputs	

Video section

Inputs	AV INPUT VIDEO (phono jack): 1 V _{p-p} , 75 ohms
Outputs	MONITOR OUT (phono jack): 1 V _{p-p} , 75 ohms

CD player section

System	Compact disc and digital audio system
Laser	Semiconductor laser (λ=780 nm) Emission duration: continuous
Laser output	Max. 44.6 μW* * This output is the value measured at a distance of 200 mm from the objective lens surface on the Optical Pick-up Block with 7 mm aperture.
Frequency response	2 Hz – 20 kHz (±0.5 dB)
Wavelength	780 – 790 nm
Signal-to-noise ratio	More than 90 dB
Dynamic range	More than 90 dB
CD OPTICAL DIGITAL OUT (Square optical connector jack, rear panel)	
Wavelength	600 nm
Output Level	-18 dBm

Tape player section

Recording system	4-track 2-channel stereo
Frequency response (DOLBY NR OFF)	60 – 13,000 Hz (±3 dB), using Sony TYPE I cassette 60 – 14,000 Hz (±3 dB), using Sony TYPE II cassette
Wow and flutter	±0.15% W.Peak (IEC) 0.1% W.RMS (NAB) ±0.2% W.Peak (DIN)

Tuner section

FM stereo, FM/AM superheterodyne tuner

FM tuner section

Tuning range 87.5 – 108.0 MHz
(50 kHz step)
Antenna FM lead antenna
Antenna terminals 75 ohms unbalanced
Intermediate frequency 10.7 MHz

AM tuner section

Tuning range MW
522 – 1,611 kHz
(with interval set at 9 kHz)
SW
153 – 279 kHz
(with interval set at 3 kHz)
Intermediate frequency 450 kHz
Antenna AM loop antenna,
External antenna terminal

Speaker

SS-W550G

Speaker system 4-way, 5-unit,
bass-reflex type
Speaker units
Woofer: 17 cm dia., cone type
Centre Tweeter: 3 cm dia., dome type
Side Tweeter: 5 cm dia., cone type × 2
Super Tweeter: 2 cm dia., dome type
Nominal impedance 6 ohms
Dimensions (w/h/d) Approx. 220 × 410 ×
335 mm
Mass Approx. 6.1 kg net per
speaker

General

Power requirements 110 – 120 V or 220 – 240 V
AC, 50/60 Hz Adjustable
with voltage selector
Power consumption 170 watts
Dimensions (w/h/d) STR-W550:
Approx. 280 × 205 ×
336 mm
HCD-W550:
Approx. 280 × 205 ×
359 mm
Mass STR-W550:
Approx. 7.0 kg
HCD-W550:
Approx. 4.3 kg
Supplied accessories: AM loop antenna (1)
Remote RM-SD70H (1)
Size AA (R6) batteries (2)
FM lead antenna (1)
Speaker cords (2)
Speaker pads (8)

Design and specifications are subject to change
without notice.

Index

A

- Adjusting
 - the audio emphasis 29
 - the sound 27
 - the volume 11, 13, 15
- Antennas 5, 9
- Automatic Source Selection 11, 13, 16

B

- Batteries 5

C

- CD player 10, 18
- CD Synchro Recording 12
- Clock setting 6
- Connecting. *See* Hooking up

D, E

- Display 5, 18, 28

F, G

- Flash 25

H, I, J, K

- Hooking up
 - optional components 7
 - optional speakers 8
 - the antennas 4, 9
 - the power 5
 - the system 4

L, M

- Loop 25

N

- Normal Play 10
- Non-Stop Play 21

O

- One Touch Play 11, 13, 16

P, Q

- Personal file 30
- Playing
 - a CD 10
 - a preset radio station 13
 - a tape 15
 - tracks in random order (Shuffle Play) 19
 - tracks in the desired order (Program Play) 20
 - tracks repeatedly (Repeat Play) 18
- Presetting radio stations 6
- Preset tuning 13
- Program Play 20
- Protecting recordings 36

R

- Radio stations
 - presetting 6
 - tuning in 13
- Recording
 - a CD 12
 - a radio program 14
 - timer recording 34
- Repeat Play 18
- Resetting the system 39

S

- Saving recordings 36
- Selecting the audio emphasis 27
- Setting the time 6
- Shuffle Play 19
- Sleep Timer 32
- Sound adjustment 27
- Speakers 4, 8
- Surround effect 28, 29

T, U, V

- Timer
 - falling asleep to music 32
 - timer recording 34
 - waking up to music 33
- Troubleshooting 37
- Tuner 6, 13
- Tuning interval 41

W, X, Y, Z

- Wake-up timer 33
- Wave 26

