



SRS-XB20


4-693-259-12(1)

©2017 Sony Corporation Printed in China




\* 4 6 9 3 2 5 9 1 2 \* (1)




# 1








DC IN 5V







CHARGE ⏱ 12 h : 00 m (500mA) CHARGE  
 ⏱ 04 h : 00 m (1.5A)












# 2





Android iPhone



# 3




[http://rd1.sony.net/help/speaker/srs-xb20/h\\_zz/](http://rd1.sony.net/help/speaker/srs-xb20/h_zz/)








LIGHT













ON











OFF



Speaker Add



Wireless Party Chain



**Android / iPhone**

**SongPal**  
<http://sonyapp.jp/songpal.html>