







SRS-XB21

4-734-036-13(1)


©2018 Sony Corporation Printed in China




1



2




3







LIGHT




ON







OFF







Android



Wireless Party Chain



Speaker Add




Sony Music Center

Android / iPhone



<http://www.sony.net/smcapp/>



Wireless Party Chain Speaker Add Party Booster



http://rd1.sony.net/help/speaker/srs-xb21/h_zz/